Texas Instruments

TI-34 Scientific Calculator

Basic Operations	2
Results	2
Basic Arithmetic	3
Percents	4
Fractions	5
Powers and Roots	6
Logarithmic Functions	6
Angle Units	7
DMS	7
Rectangular to Polar	8
Polar to Rectangular	8
Trigonometric Functions	9
Hyperbolic Functions	9
Statistics	10
Probability	12
Clearing and Correcting	12
Constants (Repeated Calculations)	13
Memory	14
Order of Operations	15
Number-System Modes	16
Boolean Logic Operations	18
Notation	19
Display Indicators	20
Error Conditions	21
In Case of Difficulty	
Service Information	
One-Year Limited Warranty	25

Basic Operations

slide case.

- To turn on the TI-34, expose the solar panel to light and press [AC/ON]. Note: Always press [AC/ON] to clear the calculator because memory and display
- may contain incorrect numbers.

 To turn off the TI-34, cover the solar panel with the

[2nd] selects the 2nd function of the next key pressed. 2nd functions are located above a key. To cancel [2nd] press [2nd] again. For example, [8] [3] finds the cube root of [8].

MODE selects a mode function. Mode functions are printed on the top half of a key. To cancel MODE, press CE/C. For example, MODE [STAT] sets STAT mode.

Results

Basic Arithmetic

The TI-34 calculates up to 12 digits and can display up to 10 digits plus a minus sign (-9,999,999,999 through 9,999,999) and a 2-digit exponent. Results with more than 10 digits display in scientific notation.

2

IU	ı
60 + 5 × 12 = 120	
Completes all pending operations.	
Changes sign of value just entered.	
1 + 8 +/- + 12 = 5.	
In binary, octal, or hexadecimal mode, [+/-] calculates the 2's complement of the number in the display.	
Parenthetical expression (up to 15 open for each pending operation). class all open parentheses.	_
digits (3.141592654).	
	Completes all pending operations. Changes sign of value just entered. 1 + 8 +/- + 12 = 5. In binary, octal, or hexadecimal mode, +/- calculates the 2's complement of the number in the display. Parenthetical expression (up to 15 open for each pending operation). closes all open parentheses. Pi is calculated with 12 digits (3.14159265359), displayed with 10 digits (3.141592654).

Percents Percentage (5% of 250) 250 × 5 2nd [%] 0.05 12.5 Ratio (Ratio of 250 to 5) 250 ÷ 5 2nd [%] 0.05 5000. Add-On (5% add-on of 250) 250 + 5 2nd [%] 12.5 262.5 Discount (5% discount of 250) 250 - 5 [2nd] [%] 12.5 = 237.5 4 **Fractions** bable c Enters a proper or improper fraction, **b/c** (**b** \leq 6 digits, **c** \leq 3 digits). When possible, improper fractions are displayed as mixed numbers. 3 ⊿4. 3 a 1/6 4 × 3 = Single-variable functions display decimal results. 1 [a½] 2 [x²] 0.25a [a 1/6] b [a 1/6] c Enters the mixed fraction a b/c. (a, b, c ≤ 3 digits each, with the total digits ≤ 8). 6 a1/6 4 a1/6 6 6_4_6. _2⊿3. 6. 2nd [d/c] Simplifies using greatest common factor (if possible), and then toggles display between improper fraction and mixed number.

Toggles display between fraction and decimal. Note: Due to display size,

.4د 30

15 ⊿2.

7_1⊿2. 15 ⊿2.

30 ab/c 4

2nd [d/c] 2nd [d/c]

2nd [d/c]

=

=

a b/c

Powers and	Roots	
1/x	8 1/x + 4 1/x =	0.375
X2	6 x ² + 2 =	38.
2nd [√x]	256 2nd [vx] + 4 2nd [vx] =	18.
2nd [∛x]	8 2nd [∜x] + 4 =	6.
y×	5 y* 3 =	125.
2nd [∛y]	8 2nd [∜y] 3 =	2.

Logarithmi	c Functions	
LOG	15.32 LOG	1.185258765
	+ 12.45 LOG =	2.280428117
2nd [10 ^x]	2 2nd [10 ^x] - 10 x ² =	0.
LN	15.32 LN	2.729159164
	+ 12.45 LN =	5.250879787
$[2nd][e^X]$.693 [2nd] [ex]	1.999705661
	+ 1 =	2.999705661

(e = 2.71828182846)

6

Angle Units DRG Cycles angle-unit setting between degrees, radians, and grads without affecting the displayed number. 2nd [DRG+] Cycles (converts) angle-unit setting between degrees, radians, and grads for display, entry, and calculation. 45 DEG 45. 2nd [DRG+] 0.785398163 RAD 2nd [DRG+] GRAD 50.

DEG

45.

DMS .

Enter DMS (Degrees/Minutes/Seconds) values as **D.MMSSs**, using 0s as necessary:

[2nd] [DRG+]

D degrees (0–7 digits)
decimal-point separator
MM minutes (must be 2 digits)
SS seconds (must be 2 digits)
fractional part of a second

For example, enter 48°5'3.5" as 48.05035.

Before using a DMS value in a calculation, you must convert it to decimal with FDD.

►DD	Interprets display as DMS and converts it to decimal.	
	30.09090 ►DD	30.1525
2nd [►DMS]	Temporarily displays curr DMS.	ent value as
	30.1525 [2nd] [►DMS]	30°09'09"

Rectangular to Polar

 $\mathbb{R}^{\bullet}\mathbb{P}$ converts rectangular coordinates (x,y) to polar coordinates (r,θ) .

Convert rectangular coordinates (10,8) to polar.

_		
AC/ON Or DRG (if necessary)	DEG	0.
10 2nd [x=y] 8	DEG	8.
R▶P (display r)	DEG	12.80624847
2nd [x=y] (display θ)	DEG	38.65980826
2nd $[X-Y]$ (display r)	DEG	12.80624847

Polar to Rectangular

2nd [P
ightharpoonup R] converts polar coordinates (r, θ) to rectangular coordinates (x, y).

Convert polar coordinates (5,30) to rectangular.

AC/ON or DRG (if necessary)	DEG	
5 [2nd] [x-y] 30	DEG	30.
2nd [P►R] (display x)	DEG	4.330127019
2nd $[x = y]$ (display y)	DEG	2.5
2nd $[x \in y]$ (display x)	DEG	4.330127019

8

Trigonometric Functions

Before using the trigonometric functions ((SiN), (COS), (TAN), (2nd) (SiN^{-1}) , (2nd) (COS^{-1}) , (2nd) (TAN^{-1}) , select deg, rad, or grad with (DRG).

AC/ON Or [DRG] (if necessary)	DEG	
90 SIN	DEG	۰. 1.
- 30 COS	DEG	0.866025403
=	DEG	0.133974596
1 (2nd [SIN-1]	DEG	90.
	DEC	90 5

Note: Before using a DMS (Degree/Minute/Second) value in a calculation, you must convert it to a decimal with [PDD].

Hyperbolic Functions

To access hyperbolic functions, press [HYP] and then the function ([HYP] SIN, [HYP] COS, [HYP] TAN, [HYP] 2nd [SIN-1], [HYP] 2nd [COS-1], [HYP] 2nd [TAN-1]).

Note: DEG, RAD, or GRAD does not affect hyperbolic

 calculations.

 5 HYP SIN
 74.20321058

+ 2=	76.20321058
5 (HYP) (2nd) [SIN-1]	2.312438341
+ 2 =	4.312438341

Statistics	
MODE [STAT]	Enters stat mode.
MODE [DEC], MODE [BIN], MODE [OCT], MODE [HEX]	Designates number mode.
AC/ON	Clears all statistical data, STAT mode, and memory.
Σ+	Enters data point.
2nd [Σ-]	Removes data point.
2nd $[\Sigma x]$	Sum.
2nd $[\Sigma x^2]$	Sum of squares.
2nd [x]	Mean.
2nd [σn]	Population standard deviation (n weighting).
2nd [σn-1]	Sample standard deviation (n-1 weighting).
2nd [n]	Number of data points.
CE/C	Clears current entry. Does not affect statistical data or memory.

Find the sum, mean, population standard deviation, and sample standard deviation for the data set: 45, 55, 55, 55, 60, 80. The last data point is erroneously entered as 8, removed with [2nd] $[\Sigma-]$, and then correctly entered as 80.

a3 00.		
AC/ON (to clear data)		
MODE [STAT]	STAT	0.
45 <u>Σ</u> +	STAT	1.
60 Σ +	STAT	5.
55 <u>Σ</u> +	STAT	3.
55 Σ+	STAT	4.
55 Σ+	STAT	5.
8 Σ+	STAT	6.
8 [2nd [Σ-]	STAT	5.
80 Σ+	STAT	6.
2πd) [Σx] (sum)	STAT	350.
2nd) [x] (mean)	STAT 58.333	33333
2nd $[\Sigma x^2]$ (sum of squares)	STAT	21100.
[2nd] [σ n] (n weighting)	STAT 10.671	87373
2nd [σ_{n-1}] ($n-1$ weighting)	STAT 11.690	45194

Probability

CE/C CE/C

ⅎ

0 (STO

A factorial is the product of the positive integers from 1

to n. (n must be a positive whole number \leq 69.) Using the digits 1, 3, 7, and 9 only one time each, how many 4-digit numbers can you form?

4 [2nd] [x!]	24.
Clearing	and Correcting
(AC/ON)	Clears display, errors, all pending operations, statistical data, STAT mode and memory. Sets DEG angle units, floating-decimal format.
CE/C	Clears value (before pressing operation key), display, errors, all pending operations. Does not affect mode, display format, angle units, memory, or statistical data.
	Note: CE/C after (1, ()), y*, (2nd (∜y), ⋈, (÷), (+), or — clears the calculator as if you had pressed CE/C (CE/C).

You can change from yx, x√y, x, ÷, +, -, AND, OR, XOR, or XNOR to another operation simply by pressing the intended key if the intended operation has a lower or equal priority.

operations.

Clears memory

Clears display and all pending

Deletes right-most character of entry.

12

Constants (Repeated Calculations)

A constant contains an operation $(\frac{+}{1},\frac{-}{1},\frac{+}{2},\frac{$

Calculate $2 \times \pi$, $4 \times \pi$, and $8 \times \pi$.

2 × [2nd] [π] =	6.283185307
4 🖃	12.56637061
8 🗐 🖰	25 13274123

WETHOLY			
0 STO	Clears memor	<i>f</i> .	
STO	Stores displayed value in memory, replacing current value.		у,
	23 STO	м	23.
	+ 2=	М	25.
RCL	Recalls value i	n memory.	
	(continued)		
	RCL	М	23.
	+ 3=	М	26.
SUM	Adds displayed	d value to memory	
	(continued)		
	4 SUM	М	4.
	RCL	М	27.
2nd [EXC]	Exchanges dis values.	played and memo	ry
	(continued)		
	3×5=	M	15.
	2nd [EXC]	м	27.

2nd [EXC]

15.

Memory

14

Orger	or Operations
1st	Expressions inside parentheses.
2nd	Single-variable functions that perform the calculation and display the result immediately (trigonometric, hyperbolic, square, square root, cube root, factorial, reciprocal, angle conversion, percent, logarithms, change sign).
3rd	Universal powers and roots.
4th	Multiplication and division.
5th	Addition and subtraction.
6th	a completes all operations

The TI-34 uses the Algebraic Operating System (AOSTM). It stores up to 6 pending operations (3 if STAT is displayed), and up to 15 levels of open parentheses.

The calculator allows you to enter a maximum of 6 pending operations. Pending operations are cleared when you press (CE/C) (CE/C), (AC/ON), (R►P), (2nd) [P►R], or [MODE] [STAT].

Number-Sy	stem Modes
MODE [DEC]	Selects decimal mode.
MODE (BIN)	Selects binary (BIN) mode and converts the integer portion of the displayed number. You can enter positive binary numbers as large as 111111111 (9 digits). Numbers beyond this are interpreted as negative (2's complement) numbers.
MODE [OCT]	Selects octal (oct) mode and converts the integer portion of the displayed number. You can enter positive octal numbers as large as 3777777777. Numbers beyond this are interpreted as negative (2's complement) numbers.
MODE [HEX]	Selects hexadecimal (DEC) mode and converts the integer portion of the displayed number. You can enter positive hexadecimal numbers as large as 2540BE3FF. Numbers from FDABF41C01 through FFFFFFFFF are interpreted as negative (2's complement) numbers.

Note: Hexadecimal numbers between 2540BE3FF and FDABF41C01 are equivalent to decimal values that are outside the range of the calculator and

16

therefore cause an error.

Calculate 16+1 and display in each number mode.

16+1= MODE [BIN]

[OCT] [MODE]

[MODE] [HEX]

17.

21.

11.

10001.

BIN

ост

HEX

MODE [DEC]	17.
In $\mbox{\rm Hex},$ for hexadecimal digits A through F, press the key marked A, B, C, D, E, or F.)
D and D are about as a superior latter and to be	

B and D are shown as uppercase letters on keyboard, but displayed as lowercase **b** and **d**. If you enter ABCDEF, for example, the display shows **AbCdEF**.

To display the 2's complement of the number in the

display, press +/-1.

Boolean Logic Operations

Logical AND, OR, XOR, XNOR, and NOT operations exist in binary, octal, and hexadecimal modes.

Except for NOT, these functions compare the corresponding bits of 2 values. The result is displayed in the current number base.

Note: Although the TI-34 does not display leading zeros for integers, logical operations treat each value as a 10-digit binary number. A displayed value of 0, for example, is treated as 000000000BIN, and a displayed value of 1 is treated as 0000000001BIN.

[AND]	0 AND 0 = 0	0 AND 1 = 0	1 AND 1 = 1
[OR]	0 OR 0 = 0	0 OR 1 = 1	1 OR 1 = 1
[XOR]	0 XOR 0 = 0	0 XOR 1 = 1	1 XOR 1 = 0
[XNOR]	0 XNOR 0 = 1	0 XNOR 1 = 0	1 XNOR 1 = 1
[NOT]	NOT 0 = 1	NOT 1 = 0	

What is the binary result of 9FHEX XOR 01HEX?

MODE [HEX]	HEX	0.
9F [XOR] 1 =	HEX	9E.
MODE [BIN]	BIN	10011110.

18

Notation		
[2nd [Sci]	Selects scientific notation for	ormat.
	12345 🖃	12345.
	2nd [Sci]	1.2345 ⁰⁴
2nd [Eng]	Selects engineering notatio (exponent is a multiple of 3) (continued)	
	2nd [Eng]	12.345 ⁰³
2nd [FD]	Restores standard notation decimal) format.	(floating-
2nd $[{\sf FIX}]n$	Sets decimal places to n (0–9), retaining notation format.	
	(continued) [2nd] [FIX] 2 =	12.35 ⁰³
r	2nd [FIX] 4 =	12.3450 ⁰³
2nd [FIX] .	Removes fixed-decimal sett	ing.
EXP	Enters exponent.	

You can enter a value in floating-decimal, fixeddecimal, or scientific notation, regardless of display format. Display format affects only results.

_

- To enter a number in scientific notation:
 - Enter up to 10 digits for base (mantissa). If negative, press +/- after entering the mantissa.
- Press EXP.
- Enter 1 or 2 digit exponent. If negative, press +/either before or after entering exponent.
- 1.2345 +/- EXP +/- 65 -1.2345 -65

М	Value other than 0 in memory.
E	Error condition has occurred.
2nd	Calculator will access 2nd function of next key pressed.
НҮР	Calculator will access hyperbolic function of next key pressed.
BIN, OCT, Or HEX	Calculator is in binary, octal, or hexadecimal mode.
STAT	Calculator is in statistics mode.
DEG, RAD, OF GRAD	Specifies angle-unit setting (degrees, radians, or grads). When you turn on the calculator, angle units are degrees.
()	1 or more open parentheses.

20

Error Conditions

When E appears in the display, the calculator will not accept a keyboard entry until you press (EE/C) to clear the error condition. ((EE/C) (CE/C) clears the condition and all pending operations.)

- Result larger than ±9.999999999 × 10⁹⁹.
- Division by zero.
- More than 15 open parentheses or 6 pending operations (3 in stat).
- Log, In, or 1/x of 0.
- Log, In, or √x of x < 0.
- Even root of a negative number.
- 0 to the 0th power, or 0th root of any number.
- Rectangular to polar when x or y has an exponent > 63.
- Tan of x = 90°, -90°, 270°, -270°, 450°, etc.
- Sin⁻¹ or cos⁻¹ of x where lxl > 1.
- Tanh⁻¹ of x where lxl ≥ 1.
- x! where x is not a positive integer ≤ 69.

Statistical errors

- 2nd [Σ-] to remove the only data point.
- Calculating x̄, σn, or σn-1 with no data points or σn-1 with one data point.
- More than 3 pending operations.

Number mode errors

- Result outside range for that number mode.
- Selecting BIN, OCT, or HEX when displayed number is outside range for that number mode.

In Case of Difficulty

- If the display is blank, expose the solar panel to adequate light. Press (AC/ON) and try again.
- Review the operating instructions.